WAVEFUN

Flex Pro Bluetooth 5.0 +AAC **English User Manual**

WAVEFUN

FC 43 (EX

.. 8 ..

Security Precautions

In order to have a proper and safe use of the headset, please read this user manual in detail and save it.

Be aware of the following guidelines when using your headset:

- 1. You should adjust the volume carefully when using the
- headset to prevent hearing damage. 2. Please stop using the headset in potentially hazardous situations to ensure your safety.
- 3. Please avoid using the headset to listen to music, make or receive calls which may cause a distraction while drivina.
- 4. Put this product and its accessories somewhere out of the reach of children, to avoid a fatal danger caused by inappropriate use
- 5. You should keep water from entering the headset, which may cause damage to the sound quality or the headset.
- 6. You should avoid turning the volume so high that you can't hear anything around you. If you feel a tinnitus or the volume is too high, please reduce the volume.
- 7. Stop using the headset if you feel obvious discomfort. irritation or have other adverse reactions.
- 8. The headset should not be stored or used at temperatures below -15 °C (5 F) or above 55 °C (131 F) which may shorten headset or battery life.
- 9. You must use the original cable to charge the Bluetooth headset, otherwise it may damage the headset. This headset uses a non-detachable built-in rechargeable battery, please do not remove the battery.

••• 2 ••• ■ To reconnect the paired headset with your

1. Keep the distance of the headset and cell phone (or

other devices being connected) within 1 meter. The

2. Switch on the headset, and the headset will enter into

3. Switch on the Bluetooth search function in your cell phone or other devices being connected. Then the

headset will automatically reconnect with the mobile

When there is an incoming call, press the MF button

When there is an incoming call, keep pressing the MF

· Press the MF button once or use your cell phone to

button for 2 seconds to reject the call, or use your cell

In standby mode, double-click the MF button to redial

reconnection mode when the blue light blinks.

phone which has connected last time.

Answer incoming call:

once to answer the call.

phone to reject the call.

Last call redialling:

Hang up a call:

hang up your call.

vour last call

Reject a call:

Overview of Headset

Overview of Flex Pro Bluetooth headset:



Charger and battery

- 1. Before charging, make sure the headset has been switched off
- 2. Plug USB cable into the charging port of headset: plug the other side of USB cable into the USB charger or other charging device. Charging will start and the red light remains bright on the headset.
- 3. Charging time of headset takes approximately 40 mins, the red light will switch off when fully charged.

- Keep pressing the MF button until blue light blinks.
- Pairing Mode:

• Keep pressing the MF button until blue and red lights blink alternatively

Switch off:

 Keep pressing the MF button until red light blinks and goes out.

Pair your headset with your cell phone:

- 1. Keep the distance between the headset and cell phone (or other devices being connected) within 1 meter. The closer the better.
- 2. Keep pressing the MF button until the blue and red lights blink alternatively.
- 3. Initiate Bluetooth function of cell phone (or other device being connected). Then "WAVEFUN Flex Pro" will be shown on your phone
- 4. Select"WAVEFUN Flex Pro" (some cell phones need you to input the PIN "0000" as password) and the headset will automatically connect with your cell phone, the blue light begins to blink. Attention: Generally, there is 120 seconds maximum to pair the headset with your cell phone, or the Bluetooth pairing mode will stop when the lights goes out. Please retry steps 1 to 4 to pair again if your operation doesn't work.

To disconnect the headset with your cell phone:

- Turn off the Bluetooth function of your cell phone.
- Or keep pressing the MF button until the red light goes out, to switch off the headset.
- Or take the headset from the cell phone to more than 10m (30ft) away.

Activate Voice Control

Press MFB for 2 seconds to activate voice assistant (like Siri), Then press MFB for 2 seconds to guit the voice assistant (Take note: For android voice assistant. you need to quit it from your mobile phone side)

FAQ

1. WAVEFUN Flex Pro Headset can't pair with Cell phone?

Ans: Please check whether your headset is in pairing mode or reconnection mode and check whether the Bluetooth function in your cell phone is on. Now check your device's Bluetooth menu and delete/forget the headset and reconnect the headset again as before.

2. WAVEFUN Flex Pro headset cannot be switched on? Ans: Please check the battery status of your headset.

3. Can I change the battery for the headset?

Ans: No. this headset use a built-in non-detachable Li-Polymer battery, it cannot be removed.

4. Can I use headset while driving?

Ans: For safety reason, we strongly recommend not to use over-ear headset to avoid distraction while driving.

5. WAVEFUN Flex Pro Headset has disconnected with your cell phone within 10 meters?

Ans: Please check if there is metal or other material within a relatively close range which may interfere with the Bluetooth connection. Bluetooth is a radio technology which is sensitive to objects between the headset and the connected device.

... 6 ...

6. I cannot hear a sound from computer or cell phone?

Ans: Please check whether the output channel of your computer is Bluetooth, that the Audio Device and Bluetooth function of your computer support A2DP profile. And please check that the volume on your headset/computer/cell phone is turned up.

Specification

Model:	Flex Pro
Style:	In ear
AAC:	Support
Wireless Type:	Bluetooth 5.0
Battery Capacity:	120mAh
Charge voltage:	DC 5V
Fast Charge :	Support
Built in Mic:	Yes
Vocalism Principle:	Dynamic
Noise reduction:	CVC8.0
Processor:	QCC3003
Operation Range:	Within 10 meters
Answer/hang up calls:	Support
Multi-point Connection:	Support
Frequency range:	2.4GHz - 2.48GHz
Frequency response:	20-20kHz
Sensitivity:	96±3dB
Resistance:	16Ω
A2DP Technology:	Support

•• 7 •••

Music Play/Pause:

Press MF button once to play/pause music.

Volume adjustment/Music selection:

 Press Vol(+) and Vol(-) once to adjust volume; keep pressing the Vol(+) and Vol(-) to select previous track or next track.

... 5 ...

mobile phone:

closer the better.